

## **FEATURES**

- ◆ 225 to 300 psi operating pressure
- ◆ Use CO<sub>2</sub> or N<sub>2</sub>/compressed air for air source
- ◆ Air-ram electronic design
- ◆ Cocker compatible barrel thread
- ◆ ACS (anti-chop system) Delrin self-lubricating field-strip bolt
- ◆ Quick-strip bolt/striker system
- ◆ Swift response adjustable trigger system
- ◆ LED user interface
- ◆ BPS (cap at 20), Sensor, Dbounce and Dwell adjustments
- ◆ Bounce-beam sensor system
- ◆ Matt finish exterior
- ◆ Blade style trigger for lighter pull
- ◆ Mid-rise feedneck
- ◆ 3-D machined body milling
- ◆ Dual regulator system
- ◆ ASA (air system adapter) system and operating pressure gauge


## **INSIDE THE PACKAGE**

- ◆ A AR - 1
- ◆ a 12 inches Cocker thread 0.693 barrel,
- ◆ an ASA style bottom-line operating pressure regulator (OPR),
- ◆ a low pressure regulator (LPR),
- ◆ a barrel blocking condom,
- ◆ an user manual,
- ◆ a warranty card, and
- ◆ a tool pack.

## **POWER SOURCE**

- ◆ AR - 1 uses a single 9V battery for its power source.
- ◆ Remove the battery from Type-R after each use.
- ◆ Use of a long life alkaline 9V battery is recommended.
  1. Remove the 3 screws located on the left side of grip using a Phillips screwdriver and lift the grip up.
  2. Find the battery terminal and install the battery inside the grip frame.

|  |   |  |
|--|---|--|
|  | <i>LPR pressure is too low</i>                | Adjust LPR pressure without paintball present            |
| <b>AR - 1</b> will not fire with sensor system on  | <i>No paintball present</i>                   | Turn on the loader                                       |
|  | <i>Sensor system is unclean</i>               | See "Sensor System Maintenance"                          |
|  | <i>Sensor system cable is jammed</i>          | Lift up the sensor system cover and reposition the wires |
|  | <i>Ball detent is damaged</i>                 | Call the authorized dealers for replacement              |
|  | <i>Paintball broke inside</i>                 | See "Bolt Maintenance"                                   |
| Air leak from barrel area                          | <i>Lack of lubrication</i>                    | Drop some oil into the valve area                        |
|  | <i>Cup seal or valve o-ring is worn</i>       | Replace them   |
| Air leak from hose fittings                        | <i>The hose fittings are not secured</i>      | Tighten them properly                                    |
| <b>AR - 1</b> will not cycle completely            | <i>Air pressure is too low</i>                | Adjust the operating pressure to 225 to 300 psi          |
|  | <i>Low battery power</i>                      | Change battery   |
|  | <i>O-ring of striker is worn</i>              | Lubrication or replacement may require                   |
|  | <i>Striker is worn</i>                        | Call the authorized dealers for replacement              |
| Breaking paintball when shooting out of the barrel | <i>Operating pressure is too high</i>         | Adjust the operating pressure to 225 to 300 psi          |
|  | <i>Barrel size does not match paintball's</i> | The stock barrel size is 0693, change it if necessary    |
| Chopping paintball internally                      | <i>Ball detent is worn</i>                    | Call the authorized dealers for replacement              |
|  | <i>Sensor system is not on,</i>               | Switch it to ON  |
|  | <i>Low battery power</i>                      | Change battery   |



|     |                       |     |                       |
|-----|-----------------------|-----|-----------------------|
| 110 | 20-W1030-000-PSI      | 5.5 | 20-A0130-301-PN010A   |
| 109 | 20-C10200-000-PN010A  | 5.4 | 20-H03100-000-PN010A  |
| 108 | 20-W1030-000-PN01     | 5.3 | 20-E1081-000-PN01     |
| 107 | 20-D75060-000-PN010A  | 5.2 | 20-D10290-104-PN010A  |
| 106 | 20-A34123-000-PN010A  | 5.1 | 20-E10101-000-PN01    |
| 105 | 20-W10420-000-P100    | 5.0 | 20-W10070-000-PB01    |
| 104 | 20-W10080-000-P100    | 4.9 | 20-W10200-000-PB01    |
| 103 | 20-E20070-000-PN010A  | 4.8 | 20-D15142-104-P100    |
| 102 | 20-G10010-000-P100    | 4.7 | 20-F10150-000-P100    |
| 101 | W50901-E1C            | 4.6 | 20-D15232-104-P100    |
| 100 | B30324-301-PN010A     | 4.5 | 20-F10194-000-P100    |
| 99  | 20-F10420-000-PN010A  | 4.4 | 20-015020-104-P100    |
| 98  | 20-F10140-000-PN010A  | 4.3 | 20-W30030-000-PN01    |
| 97  | 20-W1050-000-PN010A   | 4.2 | 20-F101330-000-P100   |
| 96  | 20-E05090-000-PN010A  | 4.1 | 20-B15102-301-PN010A  |
| 95  | 20-H1050-000-P101     | 4.0 | 20-E0212-000-PN010A   |
| 89  | 20-B20180-301-PN010A  | 3.9 | 20-F101050-000-PB01   |
| 94  | 20-D20030-000-PN01    | 3.8 | 20-W3490-000-PN010A   |
| 93  | 20-W10710-000-PN010A  | 3.7 | 20-A0110-000-PN010A   |
| 92  | 20-G10140-000-PN010A  | 3.6 | 20-D10052-102-PN010A  |
| 91  | 20-W10112-000-P100    | 3.6 | 20-D10190-000-PN010A  |
| 90  | 20-F10170-000-P101    | 3.5 | 20-W1390-000-PN010A   |
| 89  | 20-B20180-301-PN010A  | 3.4 | 20-W10120-000-PB01    |
| 88  | 20-E025070-104-PN010A | 3.3 | 20-W3490-000-PN010A   |
| 87  | 20-D05170-104-PN010A  | 3.2 | 20-A0100-101-PN010A   |
| 86  | 20-D10360-000-PN010A  | 3.1 | 20-E0190-000-PN010A   |
| 85  | 20-G10152-000-PN010A  | 3.0 | 20-H10430-000-PN010A  |
| 84  | 20-D05190-104-PN010A  | 2.9 | 20-A01130-104-P100    |
| 83  | 20-B25282-301-PN010A  | 2.8 | 20-B15264-101-PN010A  |
| 82  | 20-F10110-000-P101    | 2.7 | 20-A06070-000-PN010A  |
| 81  | 20-B25272-301-PN010A  | 2.6 | 20-F10140-000-PN010A  |
| 80  | 20-H05310-000-PN01    | 2.5 | 20-H05310-000-PN010A  |
| 79  | 20-G10100-000-P031    | 2.4 | 20-E10140-000-PN010A  |
| 78  | 20-D25050-000-P031    | 2.3 | 20-W101010-103-PN010A |
| 77  | 20-H05300-000-P031    | 2.2 | 20-W10140-000-PN010A  |
| 76  | 20-C10020-000-PN010A  | 2.1 | 20-W10100-000-PB01    |
| 75  | 20-F10290-000-PN010A  | 2.0 | 20-W10200-000-PB01    |
| 74  | 20-H05340-000-PN010A  | 1.9 | 20-H10540-000-P031    |
| 73  | 20-B20162-301-PN010A  | 1.8 | 20-H05260-000-P031    |
| 72  | 20-D05160-104-P031    | 1.7 | 20-D15282-104-PN010A  |
| 71  | 20-F10272-000-PN010A  | 1.6 | 20-A06080-000-PN010A  |
| 70  | 20-W10800-000-P031    | 1.5 | 20-E02200-000-PN010A  |
| 69  | 20-A01190-104-PN010A  | 1.4 | 20-W1310-001-P101     |
| 68  | 20-B15622-301-PN010A  | 1.3 | 20-E53304-201-PN010A  |
| 67  | 20-F02172-000-PN010A  | 1.2 | 20-W23480-000-PN010A  |
| 66  | 20-D10280-000-F101    | 1.1 | 20-W10190-000-PB01    |
| 65  | 20-F10160-000-P101    | 1.0 | 20-E101345-201-PN010A |
| 64  | 20-B01060-104-PN010A  | 9   | 20-E10304-000-PN010A  |
| 63  | 20-F01080-000-PN010A  | 8   | 20-H05380-000-PN010A  |
| 62  | 20-W10680-000-PN010A  | 7   | 20-E10861-000-P101    |
| 61  | 20-G10130-000-PN010A  | 6   | 20-W10260-000-P101    |
| 60  | 20-F10160-000-P101    | 5   | 20-E10130-000-P101    |
| 59  | 20-H10020-100-P101    | 4   | 20-W10160-000-P031    |
| 58  | 20-H10510-000-P101    | 3   | 20-W10523-000-P031    |
| 57  | 20-F10390-000-P101    | 2   | 20-B25233-301-PN010A  |
| 56  | 20-C10120-000-PN010A  | 1   | 20-E10134-301-PN010A  |

3. Replace the 3 screws to reinstall the grip.

- ✓ Make sure there are no wires been pinched when putting the grip back.
- ✓ Do not force the wire into places and ensure they are seated easily.

## AIR SOURCE

- ♦ AR - 1 will work with CO<sub>2</sub>, N<sup>2</sup> and compressed air.
- ♦ Before attaching the air system onto AR - 1 ensure the barrel blocking device is in place.
- ♦ Always use the bottom-line OPR system for ensuring the operating pressure is at 225 to 300 psi.
- ♦ Before attaching the air system, put lubrication on the o-ring of the air system valve and the thread of ASA style OPR.
- ♦ If there is an on/off switch presented on the air system, shut the air system off before connecting it onto AR - 1
- ♦ It is recommended to maintain factory stock dual regulator system for optimum performance of AR - 1
- ♦ The N<sup>2</sup>, compressed air or CO<sub>2</sub> air system can be extremely dangerous if not handle properly or misused. Only use properly certified cylinders.
- ♦ Do not throw the air system into flame or get close to it.

## N<sup>2</sup> AND COMPRESSED AIR

- ♦ N<sup>2</sup> and compressed air are recommended for best result with AR - 1
- ♦ The bottom-line OPR system could be used to utilize the pressure.
- ♦ Pin valve type air system must be use with the bottom-line OPR.

## CO<sub>2</sub>

- ♦ The tank must have an anti-siphon tub installed correctly. Liquid CO<sub>2</sub> should not be use.
- ♦ Please have a certified airsmith to install the anti-siphon system especially designed for AR - 1.
- ♦ CO<sub>2</sub> in liquid form may damage the internal of the components of AR - 1
- ♦ DAMAGE CAUSED BY LIQUID CO<sub>2</sub> WILL NOT BE COVERED UNDER THE WARRANTY.

## DISCONNECTING AIR SYSTEM

Because there might be air left inside of AR - 1 after using, follow the instructions below to release the pressure within.

1. Disconnect the loader and ensure there is no paintball inside of AR - 1
2. If there is an on/off switch presented on the air system, shut the air system off.
3. Turn off the sensor system.
4. The adjusting nut of bottom-line OPR should be almost screwed out at counter-clockwise direction ⌈ using the supplied HEX tool.
  - Turn until the adjusting nut is almost coming off, and then turn clockwise ⌉ 3 to 5 complete circles.
5. The low pressure regulator should be almost screwed out at counter-clockwise direction ⌈ using the supplied HEX tool.
6. Dry fire AR - 1 until there is no air left inside of it.
7. Disconnect the air system.

## PRESSURE ADJUSTMENT

- ALWAYS WEAR EYE PROTECTING DESIGNED FOR PAINTBALL USE WHEN FIRING THE MARKER.
- Before attaching the air system onto AR - 1 ensure the barrel blocking device is in place.
- The adjusting nut of bottom-line OPR should be almost screwed out at counter-clockwise direction ⌈ using the supplied HEX tool.
- The low pressure regulator should be almost screwed out at counter-clockwise direction ⌈ using the supplied HEX tool.
- The initial adjustment should be made with no paintball inside of AR - 1 and the sensor system set to off.
- When adjusting the operating or low pressure, always recheck the velocity using chronograph devices.
- Bottom-line OPR controls the pressure supplied to AR - 1 through the air system.
- LPR controls the pressure supplied to the solenoid when AR - 1 is fired.
- LPR will influence how hard the striker moves forward when firing; higher the pressure, harder and faster the striker will move.
- Velocity is the balance of operating pressure and LPR pressure.
- Internal damage may occur to the components or the regulator systems and the warranty may have been voided.

## OPR ADJUSTMENT

- Operating pressure can be adjusted by using the ASA style bottom-line regulator.
- DO NOT ADJUST YOUR OPERATING PRESSURE OVER 450 PSI, INTERNAL DAMAGE MAY OCCUR TO THE REGULATOR SYSTEM AND THE MARKER ITSELF.

- The suggested operating pressure is between 225 to 325 psi.
- To Increase the pressure
  - ✓ Use the supplied HEX tool to screw the adjusting nut in at clockwise direction ⌂.
- To decrease the pressure
  - ✓ Screw the adjusting nut in at counter-clockwise direction ⌂, if viewing from the front.
  - ✓ AR - 1 must be fired for the reading on the pressure gauge to drop when decreasing the pressure.

### **LPR ADJUSTMENT**



- LPR can be found on the front of AR - 1
- LPR does not use a pressure gauge to monitor its pressure adjustment.
- Adjust the LPR when the operating pressure is set at 275 psi.
- To Increase the pressure
  - ✓ Use the supplied HEX tool to the turn the adjusting nut in or at clockwise direction ⌂, if viewing from the front.
- To decrease the pressure
  - ✓ Turn the adjusting nut out or at count-clockwise direction ⌂, if viewing from the front.
  - ✓ LPR pressure will not be accurate unless AR - 1 is fired during the adjustment.
- Once the sound of firing seems right, place couple paintballs in AR - 1 to test the velocity using the chronograph devices.
  - ✓ The speed should not excess 300 f/s.
- If the solenoid starts to leak air, immediately decrease the LPR pressure.
  - ✓ After firing, the leakage should stop.
- To reach the proper velocity, increase/decrease the pressure using bottom-line OPR from here.

### **TRIGGER ADJUSTMENT**

- There is an adjusting nut located on the trigger, using the supplied HEX tool to tweak.
- Screw in at clockwise direction ⌂ will reduce the distance between the trigger and the micro switch.
- Screw out at counter-clockwise direction ⌂ will increase the distance between the trigger and the micro switch.

# LED INTERFACE OPERATION

- Before operating the PC board of AR - 1 ensure the barrel blocking device is in place.
- There are 1 operating button and 1 LED induction light; both located on the back on the grip frame of AR - 1



## ACTIVATION

- Press and hold down the operating button for 3 second.
- The LED light will then turn green and AR - 1 is now activated.
- When the LED light is red, AR - 1 is in SAFE mode.
- Press the operating button once, the LED light will now turn green; AR - 1 is now LIVE.
- If the power of the battery is low, the LED light will start to blink.
- The factory setting is to have the sensor system set to on, so AR - 1 will not fire until the paintball is loaded in AR - 1 or the sensor system is set to off.

## DEACTIVATION

- Hold down the operating button for 3 seconds.
- LED light will now turn off and the **AR - 1** is now deactivated.

## SAFETY

1. Press the operating button when **AR - 1** is activated, and the LED light will turn from red to green; **AR - 1** is now under **SAFE mode**.
2. Press the operating button again, the LED light will turn from green to red, and **AR - 1** is now LIVE.

## BOARD ADJUSTMENT

- Remove the 3 screws located on the left side of grip when **AR - 1** is pointing to the left; using a Phillips screw driver and lift it up.
- The 6 adjusting jumpers are located on the bottom of the PC board.
- Jumper 1 and 2 are used for adjusting the DWELL of the **AR - 1** which controls the solenoid valve opening time.
  - ✓ Higher the Dwell, more of the pressure been released.
- Jumper 3 and 4 are used for adjusting the DBOUNCE, which controls the trigger sensitivity.
  - ✓ Higher the Dbounce, more sensitive the trigger is.
- Jumper 5 controls BPS setting.
- Jumper 6 controls the SENSOR system on/off.
- Below is a table showing the meaning of the jumper adjustment.
  - ✓ ↑ is to push the jumper up; ↓ is to pull down.

| DWELL  |         | DBOUNCE |         | BPS    |         | SENSOR |         |
|--------|---------|---------|---------|--------|---------|--------|---------|
| switch | setting | switch  | Setting | switch | setting | switch | Setting |
| ↓↓     | 6 ms    | ↓↓      | 8 ms    | ↑      | 20 BPS  | ↑      | ON      |
| ↑↓     | 8 ms    | ↑↓      | 16 ms   |        |         |        |         |
| ↓↑     | 10 ms   | ↓↑      | 21 ms   | ↓      | 15 BPS  | ↓      | OFF     |
| ↑↑     | 12 ms   | ↑↑      | 28 ms   |        |         |        |         |

- After the adjustment is finished, replace the grip and 3 screws back.

## EXTERNAL MAINTENANCE

1. Most contaminates found on external surface could often easily remove by using water alcohol mix and a dry clean dump cloth.

2. This is recommended to keep a clean rag, Q-tips and a small amount of the water alcohol mix with the tools.

## SENSOR SYSTEM MAINTENANCE

The sensor system must be kept clean for optimal performance, please follow the below instructions for cleaning and maintenance”

1. Remove the screw on the sensor system cover with supplied HEX tool.
2. Remove the sensor system and its cover.
3. Clean the area thoroughly with cotton swab and rubbing alcohol.
4. Replace the sensor system and the cover back.
5. Replace the screw back to the sensor system cover.

## BOLT MAINTENANCE

**AR - 1** is equipped with a Delrin fieldstrip bolt for durability and reducing friction.

- The bolt must be kept clean for optimal performance.
- The Delrin bolt does not require lubrication.
- If the surface of the bolt become sticky, please use the following cleaning instructions:
  1. Make sure the air system is not attached to **AR - 1** and there is no paintball inside.
  2. Lift up the locking pin on the left and remove the bolt from the rear.
  3. Clean the bolt with a dry clean dump cloth; soap and warm water may be used to remove contaminates.
  4. Lubricate the bolt and the o-rings on it very lightly.
  5. The pin locking system should be oiled to ensure the correct function.
    - ✓ Do the oiling very gently and minimize the oil use on the bolt itself.
  6. Clean the bore of **AR - 1** with a squeegee and ensure no contaminates are presented.
  7. Replace the bolt back to **AR - 1** and check for movement; it should now move freely in the bore.

## STRIKER MAINTENANCE

Follow the below instructions to remove the striker assembly carefully for cleaning and maintenance:

1. Disconnect the air system and loader and ensure there is no paintball inside of **AR - 1**
2. Use a slotted screwdriver to unscrew rear hose connector from the ram cap.
3. Remove the striker/bolt horizontally locking pin in the rear of the body.

4. Remove the striker/bolt system in one piece from the rear of AR - 1
5. Place each component carefully and pay attention to their settings.
6. Pull the striker out from ram cap and there is a smaller o-ring located on the rear end of the striker, which will require some gel type lubricant.
  - ♦ Replace the o-ring if the wear is excessive.
7. Clean the bore of AR - 1 with a squeegee and ensure no contaminants are present.
8. Reassemble the components and slip them back to the respective chambers from rear of AR - 1 the way they were taken out.
9. Screw the hose connector back to ram cap and reinstall the striker/bolt horizontally locking pin in the rear of the body.

## FIRING VALVE MAINTENANCE

Follow the below instructions to remove the firing valve assembly carefully for cleaning and maintenance:

1. Follow the step 1 to 5 in the "STRICKER MAINTENANCE."
2. After taking out the striker/bolt system, also take out the spring.
3. Use a slotted screwdriver to unscrew the rear hose connector from the LPR.
4. Using the supplied HEX tool to remove the 2 screws, which attach the grip frame to the body.
5. The grip frame will now come off free, and unscrew the carrier screw, which is located under the body, with the supplied HEX tool.
  - ♦ Use couple drops of gel type lubrication on the carrier screw.
6. Using the supplied HEX tool to remove the screw, which attaches the LPR to the body and detach the LPR.
  - ♦ Use couple drops of gel type lubrication on the screw.
7. Remove the firing valve guide which can be seen after detach the LPR.
8. Use a long and narrow object, such as the back of the pen, to push out the firing valve.
9. Paintball specific oil lubrication should be used on the firing valve and its o-rings.
  - ♦ Replace o-rings if they are worn.
10. Clean both chambers with a squeegee and ensure no contaminants are present.
11. Place the firing valve back using a long and narrow object and reinstall the carrier screw.
12. Replace the firing valve guide and LPR, and reinstall the screw, which attaches the LPR to the body.
13. Reinstall the carrier screw under the body to position the firing valve.
14. Carefully place the pressure hoses in the 2 hose slots on top of the grip frame and reinstall the 2 screws, which attached the grip frame to the body..

- Ensure the hoses and the sensor system cable are not pinched.
15. Replace the spring and striker/bolt system, and reinstall the front and rear hose connectors.
16. Follow the step 8 and 9 in the “STRICKER MAINTENANCE.”

## STORAGE AND TRANSPORTATION

- Clean and deactivate AR - 1 as well detach the air system when it is not in use.
- Make sure the barrel blocking device is in place when AR - 1 is not in use.
- Keep Type-R away from any unauthorized users.
- During transportation, AR - 1 must be free of any air source to and from the playing fields.
- Do not carry AR - 1 uncased when not on a playing field, because non-playing public and law enforcement personal may not be able to recognize between a paintball marker and firearm.
- Always carry AR - 1 in its factory case or a suitable marker case.
- Never transport charged N<sup>2</sup>/compressed air or CO<sup>2</sup> air system.

## TROUBLESHOOTING

| PROBLEM                      | POSSIBLE CASUE  | SOLUTION   |
|------------------------------|---|--|
| Pressure gauge will not move | <i>The pressure used was too high for the gauge to handle</i> | Replace the gauge  |
| AR - 1 will not turn on      | <i>Not activated</i>  | Press and hold down operating button for more than 4 seconds               |
|                              | <i>Low battery power</i>                                      | Change battery   |
|                              | <i>Battery is connected incorrectly to the PC board</i>       | Check to see if the battery cable were connected correctly to the terminal |
| AR - 1 will not fire         | <i>Low battery power</i>                                      | Change battery   |
|                              | <i>Solenoid may be out of place</i>                           | Open grip and press solenoid forward                                       |
|                              | <i>Low air</i>  | Refill the air system  |
|                              | <i>Air system is not screwed in</i>                           | Screw in the air system  |